

YetiCam LLC

www.YetiCam.com


Please note that making modifications to this camera will void all warranties to the camera and could damage the camera beyond repair. YetiCam LLC is not responsible for any injuries or damage created by use of this document.

Notes for doing a Neuros Recorder Setup

- The chip included has different functions for switches 6&7 then the DIP switch sticker shows. These switches are used to control movie lengths. These switches operate like:
 - Off, Off ~ 10 seconds
 - On, Off ~ 30 seconds
 - Off, On ~ 60 seconds
 - On, On Records until 15 seconds after no motion detected
- Switch 5 must be in Movie Mode
- To wire the power board follow the following picture below. Be very careful with polarity so you don't burn up your camera or Neuros recorder.
- There are links to the Neuros remote control hack document located at these two locations:
 - <http://www.hagshouse.com/forums/index.php?showtopic=24441&hl=neuros+remote>
 - <http://www.hagshouse.com/forums/index.php?showtopic=28535&hl=neuros+remote>

YetiCam LLC

www.YetiCam.com



The 5Vo terminals are swtiched on and off with movement. These should be hooked to the Neuros recorder.

The 12 Vi terminals are for hooking the supply battery up to.

The 12 Vo terminals are swtiched on and off with movement. These should be hooked to a 12V camera.